



## Remove Polyimide from the Tips of CE Capillaries - Tech Information

*Date: 22-APRIL-2012 Last Updated: 1-NOVEMBER-2025*

By burning off 2 mm of the inlet and outlet ends of the non coated capillaries, the injection precision of your CE unit will improve. It is believed that the reason for the improvement is prevention of the polyimide from swelling due to prolonged exposure to NaOH.

Click [HERE](#) for MICROSOLV Window Maker ordering information and pictures.

Printed from the Chrom Resource Center

Copyright 2025, All Rights Apply

**MicroSolv Technology Corporation**

9158 Industrial Blvd. NE, Leland, NC 28451

Tel: (732) 380-8900

Fax: (910) 769-9435

Email: [customers@mtc-usa.com](mailto:customers@mtc-usa.com)

Website: [www.mtc-usa.com](http://www.mtc-usa.com)